

## 5.1.1 ENTERING SP MODE

If there are no Classic Application (copy/printer/scanner/fax) icons on the HOME screen, follow the procedure below to display the number keyboard.

1. Press and hold the button [A] located at the left side of the operation panel and "Check Status [B]" at the same time, until the number keyboard is displayed.



2. Enter the key code for SP mode.



*For details of the key code to enter the SP mode, ask your supervisor.*