

# Intermittent DF jams

On the 5054 and like machines, If the customer is complaining about jamming in the DF check that the Mylar shown in attached photo is clean, if enough dirt/dust gets in the area it will give you intermittent jams.



